

**[H] Solutions to Problems**

- 1) **To sand bottom of narrow opening vessel ?**
  - use forceps with ball of steel wool with or without a sandpaper wrapping
  
- 2) **To sand vibrating wood ? ( out of round )**
  - use power 5" orbital sander with soft backed disc holder with very slow turning speed and slowest sander speed.
  
- 3) **To keep a crisp edge or rim while sanding ?**
  - use "triangle" Detail Sander ( they have only 3/32" orbit )
  
- 4) **Trying to "sand" cracks, holes and other imperfections away ?**
  - ( can leave dips or not work at all )
  - use dust from same vessel as filler
    - before final sanding use sanding dust, or screened shavings, to fill any opening larger than a hairline crack.
    - first saturate nearby surface with 1 - 2 glue Accelerator before adding instant glue and dust.
      - ( possible to use sanding sealer instead; but it will not evaporate like Accelerator )